

If gauge Reads	Number of Gallons Remaining					
	120	150	200	250	330	500
80%	100	120	160	200	264	400
70%	84	105	140	175	231	350
60%	72	90	120	150	198	300
50%	60	75	100	125	165	250
40%	48	60	80	100	132	200
30%	36	45	60	75	99	150
If gauge reads less than 20%, order gas now!						
20%	24	30	40	50	66	100
10%	12	15	20	25	33	50



[How to read the percentage on your tank](#)

Look at your gauge attached to the tank with numbers from 5-95. Numbers indicate the Percentage of gas remaining in the tank. If your tank gauge reads 25% or less, call your propane supplier for a refill. We recommend that you learn how to read your tank gauge, and develop the habit of checking it on a regular basis, especially if you choose not to participate in our company's **Keep – Full** program.

